# **User Guide**

# **Spectrum Recorder API**

# RF Spectrum Data Logger API v1 – Firmware v3.2



#### **Overview**

The Spectrum Recorder API allows clients to retrieve sweep data from a Spectrum Recorder device connected to a network. This data includes amplitude information encoded in a base64 string and relevant configuration values such as RBW (Resolution Bandwidth).

**Note:** This user guide applies to devices using Firmware 3.2 or later. Go to <a href="https://www.rfvenue.com/spectrum-recorder-3.2-firmware-update">https://www.rfvenue.com/spectrum-recorder-3.2-firmware-update</a> to get the latest firmware upgrade and directions.

#### **Endpoints**

API URL	Description
GET /api/v1/Sweep/GetSweep	Latest realtime activity, normally updated every 20 seconds with standard span configuration  Note this realtime data is only available through the API not from CSV files
GET /api/v1/Sweep/GetSweep24Avg	Latest 24hs Average Hold, same as Avg.csv file
GET /api/v1/Sweep/GetSweep24Max	Latest 24hs Max Hold, same as MaxHold.csv file
GET /api/v1/Sweep/GetSweep24Acti	Latest 24hs Activity, same as Active.csv file
GET /api/v1/Sweep/GetConfig	Current Configuration settings
POST /api/v1/Sweep/UpdateFrequer	Change Start/Stop/Step frequency (new in v3.2)

## **Sweep Response Format**

The response headers include configuration details:

- X-RBW: The Resolution Bandwidth (RBW) value in KHz.
- X-StartFreq: The starting frequency of the sweep in MHz.
- X-StopFreq: The stopping frequency of the sweep in MHz.
- X-InputStage: The input stage setting (either Direct or LNA). Note: this is currently fixed in hardware and always operates in Direct mode.
- X-CRC32: Binary sweep checksum

The sweep response body is packed in a byte array representing amplitude data, which is then compressed with GZip and base64-encoded in a string. This is required to reduce communication latency for the 12K points transmitted. The algorithm to restore the sweep data is as follows:

- 1. Decode base64 to get the compressed byte array.
- 2. Decompress the byte array to get the uncompressed byte array.
- 3. Check that the uncompressed byte array CRC32 matches the one received in the header.
- 4. Convert the byte array into a float array with amplitude data in dBm/dB using the following calculations:
  - a. If sweep data type is not GetSweep24Active, then calculate each iByte element:

```
float fDBM = iByte/-2.0
```

This will provide possible values ranging from -120 to 0 fDBM with 0.5dB resolution.

b. If sweep data type is GetSweep24Active, then calculate each iByte element

```
float fDB = iByte/2.0
```

This will provide possible values ranging from 0 to +120 fDB with 0.5dB resolution.

Refer to Python code example function decompress string to understand the algorithm logic.

©2025 RF Venue, Inc. • (800)795-0817 • +1-781-386-0687 • orders@rfvenue.com • www.RFvenue.com

Page 1 of 4

UG-00002 rev A





## **Config Response Format**

The response body is empty for configuration data request and can be ignored.

The response headers include configuration details:

- X-RBW: The Resolution Bandwidth (RBW) value in KHz.
- X-StartFreq: The starting frequency of the sweep in MHz.
- X-StopFreq: The stopping frequency of the sweep in MHz.
- X-InputStage: The input stage setting (either Direct or LNA).
- X-SN: Device Serial Number
- X-Model: Device model
- X-FWVER: Device Firmware Version
- X-Date: Current Date/Time UTC
- X-TZ: Current Time zone
- X-Loc: Current location
- X-Files: Total Files available

#### **Update Frequency Details**

Starting with firmware version 3.2, it is now possible to change the frequency configuration using the API as well as the GUI.

The format uses the route: /StartFrequency(MHz)/StopFrequency(MHz)/StepFrequency(KHz)

For example, to start at 300.125 MHz and stop at 400 MHz with a 25 KHz step, you can use curl as shown below:

curl -i -X POST http://192.168.1.55:80/api/v1/Sweep/UpdateFrequency/300.125/400/25

The response headers include configuration details:

- X-RBW: The Resolution Bandwidth (RBW) value in KHz.
- X-StartFreq: The starting frequency of the sweep in MHz.
- X-StopFreq: The stopping frequency of the sweep in MHz.
- X-InputStage: The input stage setting (either Direct or LNA). Note: this is currently fixed in hardware and always operates in Direct mode.

If the input values are invalid, two things may happen:

- If values are completely out of range (15–2700 MHz with a minimum span of 10 MHz), the device will return status code 500 to indicate failure, and the command will be ignored.
- If values are within range but need adjustment, the firmware will internally adjust them to valid values and return success using the new adjusted values.

#### **Additional Notes:**

- In all cases, the caller must check the response headers to confirm that the applied values match the expected configuration.
- RBW is determined automatically based on the requested step frequency.
- A maximum of 50,000 data points is allowed per scan; otherwise, values will be internally adjusted to stay within that limit.
- You can estimate the number of data points with the formula: (StopFrequency StartFrequency) / StepFrequency
- Note: Frequencies are in MHz, while StepFrequency is in KHz. Be sure to convert units properly when calculating.



#### **Example curl GetSweep Request**

curl -i -X GET http://LOCALIP/api/v1/Sweep/GetSweep

#### **Example Response**

• Status Code: 200 OK

Headers:

• Content-Type: application/json; charset=utf-8

• X-RBW: 25

X-StartFreq: 470.000X-StopFreq: 950.000X-InputStage: Direct

Body: "eHhhbXBsZUJhc2U2NEVuY29kZWREYXRheHhbbXBsZUJhc2U2NEVuY29kZWREYXRh"

#### **Error Handling**

- 404 Not Found: The specified resource was not found.
- 500 Internal Server Error: An unexpected error occurred processing your request.

## **Python Example**

As a fully functional implemented example, the python spectrum\_recorder\_api\_client.py file includes call to each API function, decoding data, CRC32 check and data display on screen.

To run it using Python 3.x, you need to install this lib first

```
pip install requests
```

Then run the example providing IP address of the SpectrumRecorder (local and remote network are ok) and specify port (local port is always 80, use a mapped port if accessing remotely)

```
python3 spectrum_recorder_api_client.py 192.168.1.55 80
```

Example result is listed below:

```
----- METHOD GetSweep -----
Resolution BandWidth: 25KHz
Start frequency: 400.0MHz
Stopping frequency: 699.975MHz
Input Stage: Direct
CRC32 Hex: F693098D (received OK)
Total Sweep points: 12000
Minimum amplitude: -110.0 dBm
Maximum amplitude: -57.5 dBm at 627.9 MHz
     -----
----- METHOD GetSweep24Max -----
Resolution BandWidth: 25KHz
Start frequency: 400.0MHz
Stopping frequency: 699.975MHz
Input Stage: Direct
CRC32 Hex: 509D1E3B (received OK)
Total Sweep points: 12000
Minimum amplitude: -93.0 dBm
```

Maximum amplitude: -40.0 dBm at 433.875 MHz

©2025 RF Venue, Inc. • (800)795-0817 • +1-781-386-0687 • orders@rfvenue.com • www.RFvenue.com



#### Spectrum Recorder API v1 - Firmware v3. 2

----- METHOD GetSweep24Avg ------Resolution BandWidth: 25KHz Start frequency: 400.0MHz Stopping frequency: 699.975MHz Input Stage: Direct CRC32 Hex: 5D16F6D1 (received OK) Total Sweep points: 12000 Minimum amplitude: -104.0 dBm Maximum amplitude: -61.0 dBm at 400.025 MHz ----- METHOD GetSweep24Active -----Resolution BandWidth: 25KHz Start frequency: 400.0MHz Stopping frequency: 699.975MHz Input Stage: Direct CRC32 Hex: F9BA23AA (received OK) Total Sweep points: 12000 Minimum amplitude: 1.0 dB Maximum amplitude: 60.0 dB at 433.875 MHz \_\_\_\_\_\_ ----- METHOD GetConfig -----Resolution BandWidth: 25KHz Start frequency: 400.000MHz Stopping frequency: 699.975MHz Input Stage: Direct Device Serial Number: B34K-55L7-389C-9879 Device model: Spectrum Recorder v1 Device Firmware Version: 3.0.2406.2 Current Date/Time UTC: 2024/06/28 11:51:18 Current Timezone: (UTC+02.00) Europe/Madrid Current location: Mount Aconcagua Total Files available: 1584